

Detector room

When X-ray unit is not being used, all keys must be stored in key cabinet!

Access to key cabinet is controlled by the responsible operator!

X-ray badges must be worn when entering interlocked areas!

Entering

- 1) Obtain permission from operator to enter room
- 2) Enter date and time of entry in logbook and name of all personnel seeking entrance
- 3) Retrieve key number 5 from key cabinet
- 4) Unlock padlock using key number 5, slide open door and lock in place with padlock

Exiting

- 1) Ensure beam stop is secured
- 2) Account for all personnel
- 3) Unlock padlock using key number 5, slide door shut and lock in place with padlock
- 4) Ensure calibration room service hatches are secured
- 5) Ensure all personnel entered in logbook is accounted for
- 6) Return key number 5 to operator